

LABORATORY PROGRAM – 8

Configure Web Server, DNS within a LAN.

18/12/24 LAB No. 11

PAGE NO :
DATE :

Aim: Configure Web Server, DNS within a LAN

Topology:

```
graph TD; PC[PC 10.0.0.1] --- Switch[Switch]; Switch --- Server[Server 10.0.0.2]
```

Procedure:

1. Set up the LAN as per the topology mentioned above and Configure the devices
2. Go to Server → Services → DNS:
Name: browse [Domain name]
Address: 10.0.0.2
Add the mapping of domain name to address
3. Go to PC → Config → Global → Settings → DNS Server: 10.0.0.2
[The Server that provides the DNS mapping]
4. Go to PC → Desktop → Web Browser
Type the URL: http://browse

Observations:

- 1) The Webpages hosted by the Server will be visible on the browser.
- 2) The DNS was successful in mapping the domain name to the IP address.
- 3) DNS Server is a server that contains a Domain name: IP address mapping to which the end devices send requests to map the Name to IP address.

